

Installation and Operation of the TITAN-24

SAFETY WARNINGS

USE COMMON SENSE!

Only qualified personnel should service this equipment.

The battery contains hazardous currents and may present a burn hazard if damaged, shorted, or installed improperly.

USE ONLY GS BATTERY MODEL GT12080-HG and ESPi MODEL DCSP1150200 AC/DC ADAPTER

The following precautions should be followed to insure your safety:

- Remove watches, rings, or other metallic objects.
- Wear protective clothing and eye protection when working with batteries.
- Always carry a water supply to wash eyes or skin in the event of exposure to battery electrolyte.
- Use of tools with insulated handles is required.
- Do not disassemble the unit. No user-serviceable parts are inside except the battery.
- Keep liquid and foreign objects from getting inside the unit.
- Avoid operating unit in excessive humidity or near water.
- Do not operate near gas or fire.
- Inspect unit for leaking substance. If substance is leaking, do not use product.
- Servicing this equipment may require working with protective covers removed and utility power connected. Use EXTREME CAUTION during these procedures.
- Check that power cord, plugs, and output terminals are in good working order.

FUSE REPLACEMENT

- Fuse rating is 3A, 32VDC. This is a fast blow type of fuse.
- If the fuse on the unit should fail, replace it with a Littelfuse part number 0297003 or other certified fuse with the same rating/operating characteristics.
- Before replacing a failed fuse, consider examining the unit for signs of a hardware fault that could result in subsequent fuse failure, damage or safety hazard.

PRIMARY CIRCUIT PROTECTION

- AC Adapter shall be inserted in an AC outlet that is protected by a properly rated branch circuit per national or local codes.


BATTERY WARNINGS

- Danger of explosion if battery is incorrectly connected or replaced with an incorrect type. Use only approved replacement batteries. (GS BATTERY MODEL GT12080-HG) Contact ESPi for replacement.
- Worn out or damaged batteries are considered environmentally unsafe. ALWAYS recycle used batteries in accordance with all federal, state, and local regulations. This is your planet too.
- Any gel or liquid emissions from a VRLA battery contain sulfuric acid, which is harmful to the skin and eyes.
- Batteries can produce explosive gases. Avoid all open flames and sparks.
- Batteries contain or emit chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Battery post terminals contain lead and lead compounds. Wash hands after handling. (California Proposition 65)
- Wear protective clothing and eye protection when installing, maintaining, servicing, or replacing batteries.
- If battery emissions contact the skin or eyes, immediately wash area with water. Report chemical spills and seek medical attention if necessary.
- Always replace batteries with new batteries of identical type and rating.
- A battery showing signs of cracking, leaking, or swelling should be replaced immediately with an approved battery.


WIRING DIAGRAM

- ALWAYS support the unit from the bottom with your hand or place on a firm surface.
- Output and Alarm Connectors: The TITAN -24 output wiring is as follows: +,-,On battery, Replace Battery, Battery missing, low battery, Battery failure. Once wiring is complete, push down on the unit as you slide the TITAN -24 UPS over a battery. The enclosure has a groove that will contain the battery and lid.

Output and Alarm Connectors: The TITAN -24 output wiring is as follows:
+,-,On battery, Replace Battery, Battery missing, low battery, Battery failure.



Once wiring is complete, push down on the unit as you slide the TITAN -24 UPS over a battery. The enclosure has a groove that will contain the battery and lid. ►



INSTALLATION


- Installation of the unit must be performed by skilled technicians and electricians familiar with electrical equipment. Do not allow unqualified personnel to handle, install or operate equipment.
- **MAX DISTANCE:** The TITAN -24 UPS has been engineered for a maximum distance between the AC outlet and the UPS. The recommended cable from the switching power supply and the UPS is 16 AWG cable for cable runs up to 115'. From the UPS to the ONT, the maximum distance is 70'. Install the unit in a sheltered location away from gas, fire, potential sparks, water, and rain.

MOUNTING ORIENTATION

- **WALL MOUNT:** Choose your mounting location. Locate a stud within the wall. Pre-drill holes suitable for appropriate screw size. #10- 1 1/2" pan head sheet metal screws are suggested. Choose an appropriate screw for the material. Place screws in vertical alignment on stud at 2 1/4" apart vertically. This will allow the NEO to fit over the screws and slide down into a secure position. To remove from the wall slide the unit up holding the unit from below and then remove from the wall. One screw should be fastened into a stud. Screws should be part of an anchoring system this is rated to support 20 pounds per screw.

• POLE MOUNTING


The TITAN UPS has been designed to mount on a 2 1/4" pole. Pre-drill the top two holes in the enclosure. Put a "U" shaped bracket through holes so that two prongs are out the back. Install security bracket on the outside of the pole and tighten nuts against the bracket. Do not use a bracket where the U shape will protrude into the enclosure and interfere with the battery/electronics.



WIRING:

- Use 16 AWG wire rated for operation at 75C or higher.
- If wire will be exposed to sunlight, insulation must be UV rated.
- Solid copper conductors are recommended.
- If stranded wire is used, the ends should be tinned before installation.
- Wire shall be flame resistant per local and national codes.
- Wire should have a minimum voltage rating of 30V DC.


Connect the switching power supply to the input side of the UPS. The screw terminals are labeled "+" and "-". Connecting the power wires backwards will not damage the unit but will cause the unit to not charge the battery. Plug in the switching power supply and connect the ONT. USE ONLY THE ESPI MODEL DCSP150200 AC/DC ADAPTER!



USE ONLY THE GS BATTERY MODEL: GT12080-HG. (OTHER BATTERIES WILL CAUSE GASSING AND WILL EXPLODE!)

OPERATIONAL LED

- The TITAN -24 UPS has been designed for easy operation and notification of battery status as follows:
- Green light solid = normal operation and AC power is present
- Green Flashing = Battery is in Test Mode
- Yellow light blinking = unit is providing output from the battery. No AC is present
 1. Blinking once per second = > 66% run time available
 2. Blinking two times per second = 33% to 66% run time available
 3. Blinking three times per second = < 33% run time available
- Red light solid = Battery failed and must be replaced
- Red Flashing = Battery is missing or not connected. Check lid position.
- Red + Yellow = Temperature above +150°
- All Three Flashing = Short Circuit between the UPS and ONT



CONTROLS:

Reset Button: The red reset button on the front will temporarily disconnect power to the output device causing a reset of the ONT.

Cold Power ON: This button is located next to the power input. Use a non-metallic device such as a toothpick to activate. (Must hold cold start button down for 3 seconds to activate.) If AC power is not available, pressing the "COLD POWER ON" button will activate the UPS.

Off Switch: To turn off the unit for long periods of storage, unplug the switching power supply from the wall and press the reset button on the front. To turn on the UPS, plug in the switching power supply. Remove the battery from the unit if it shall be left un-powered for more than 3 months.

Maintenance Mode: The TITAN -24 UPS will diagnose the battery every 45 days. The TITAN -24 will run a 3-hour battery test to determine current battery state. If it fails this test, the solid RED LED will come on signifying the battery is at the end of its useful life. GREEN LIGHT FLASHING INDICATES TESTING IN PROGRESS.

Battery Replacement: When replacing the battery take care at all times not to short out the battery terminals. Remove the unit from the wall by sliding upwards. Remove two screws from the back of the unit. Turn unit upside down to remove battery and slide lid off. CAUTION: support the battery with your hand during removal. The lid will not support the weight of the battery. Care must be taken to hold the battery and not just the lid. Failure to do so will result in the battery falling and possibly causing injury. NEO - Remove the two screws located on the back of the UPS. Turn unit upside down to remove the battery while supporting the battery with your hand. Never use the lid as a support. Failure to do so will cause the battery to fall possibly causing damage to you. Once this is complete, pull up on the tab located on the right side and pull the battery to the left. To replace the battery, slide the cover over the left side of the battery until the latch clicks. Place entire unit back in the enclosure and reinstall screws. The TITAN -24 UPS includes a temperature probe that must follow the groove on the arm of the circuit board cover. This probe will determine the battery temperature and provide a precise and exact charging of the battery.

Expected Battery Life: The combination of temperature compensated charging and the best battery available: the GS MODEL: GT12080-HG BATTERY WILL PROVIDE THE LONGEST BATTERY LIFE.

The recommended temperature range for maximum battery life is 4F to 122F. The TITAN -24 has been designed to stop charging the battery if the temperature is outside of this range.

Warranty: ESPI LLC is very proud of the product we have created. Should you need support please call 877-799-3774 or visit espicorp.com.

ESPI LLC warrants to you, the Initial Purchaser, that the Product will be free from defects in material and workmanship for three years from the date of original purchase, subject to the terms of this Limited Warranty. This Limited Warranty gives you specific rights, and you may have other rights, which vary from State to State or Province to Province. Any Implied Warranty of Merchantability or for Fitness for a Particular Purpose, if applicable to the Product, is limited in duration to three years. This provision shall NOT create any Implied Warranty of Merchantability or of Fitness for a Particular Purpose that would not otherwise apply to the Product. NOTE: Some States and provinces do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

To be covered you must still be the owner of the Product at the time of the failure that results in the claim made under this Limited Warranty. Your sole and exclusive remedies are those provided by this Limited Warranty. This exclusion of other express warranties applies to written and oral express warranties. ESPI excludes any liability for personal injury. ESPI excludes any liability for direct, indirect, special, incidental, or consequential damages, whether for damage to or loss of property, loss of profits, business interruption, or loss of information or data. This exclusion applies even though damage or loss is caused by negligence or other fault. NOTE: Some States or Provinces do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation may not apply to you.

DO NOT USE FOR MEDICAL OR LIFE SUPPORT EQUIPMENT OR OTHER HIGH RISK ACTIVITIES.

ESPI does not sell the PRODUCT for use in high-risk activities. The PRODUCT is not designed or intended for use in hazardous environments requiring fail-safe performance, including the operation of nuclear facilities, aircraft navigation or communication systems, air traffic control, weapons systems, life support or medical applications or for use in any circumstance in which the failure of the PRODUCT could lead directly to death, personal injury, or severe physical or property damage, or that would affect operation or safety of any medical or life support device (collectively, "High Risk Activities").

ESPI LLC expressly disclaims any express or implied warranty of fitness for High Risk Activities. ESPI LLC does not authorize use of any of our products in any High Risk activities.

ANY SUCH USE IS IMPROPER AND IS A MISUSE OF An ESPI PRODUCT.

The Limited Warranty is governed by the laws of the United States and the State of Kansas, without reference to conflict of law principles. The application of the United Nations Convention of Contracts for the International Sale of Goods is expressly excluded.